

HONDA P/N 46505-SA5-000 (WHITE CIRCULAR GROMMET SEEN IN PIC AT TOP OF PEDAL ARM) SNAKE SELF INTO FOOTWELL, PRESS CLUTCH TO CREATE ROOM FOR P/N, INSERT W. POINTER DOWN, RELEASE. TRY ENGAGING CRUISE CONTROL NOW.



SALLY02